





NCH-3 Voodoo Vibe User manual

Copyright

copyright 2022 Cherub Technology Co. All rights reserved. NUX and Voodoo Vibe (NCH-3) are trademarks of Cherub Technology Co. Other product names modeled in this product are trademarks of their respective companies that do not endorse and are not associated or affiliated with Cherub Technology Co.

Accuracy

Whilst every effort has been made to ensure the accuracy and content of this manual, Cherub Technology Co. makes no representations or warranties regarding the contents.

WARNING!-IMPORTANT SAFETY INSTRUCTIONS BEFORE CONNECTING, READ INSTRUCTIONS

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture. CAUTION: To reduce the risk of fire or electric shock, do not remove screws. No user-serviceable parts inside. Refer servicing to qualified service personnel.

CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of FCD Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undestined operation.



The lightning symbol within a triangle means "electrical caution!" It indicates the presence of information about operating voltage and potential risks of electrical shock.



The exclamation point within a triangle means "caution!" Please read the information next to all caution sions.

- Use only the supplied power supply or power cord. If you are not sure of the type of power available, consult your dealer or local power company.
 Do not place near heat sources, such as radiators, heat registers, or appliances which
- Do not prace near near sources, such as radiators, near registers, or appliances which produce heat.
- 3. Guard against objects or liquids entering the enclosure.
- 4. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
- 5. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally or has been droposed.
- The power supply cord should be unplugged when the unit is to be unused for long periods of time.

- Protect the power cord from being walked on or pinched particularly at plugs, convenience recentacles and at the point where they exit from the apparatus
- Prolonged listening at high volume levels may cause irreparable hearing loss and/or damage. Always be sure to practice "safe listening".

Follow all instructions and heed all warnings KEEP THESE INSTRUCTIONS!

Overview

Voodoo Vibe (NCH-3) is a mini Uni-vibe pedal with 2 different modes including Vibe and Chorus. You can switch the modes by tapping the tap switch. Old-school Uni-vibe delivered its huge 3D sound by simulating the physical Rotating Speaker Effect, that beautiful and unforgettable sound easily associated with Hendrix's bending facial expressions in his 70s stage performances.

Voodoo Vibe was inspired by Dunlop® Uni-Vibe® for its gorgeous sound.

NUX's modern-tech DSP yields a perfect combination of both worlds: analog and digital. Unlike the original Uni-vibe, now you can feed Voodoo Vibe with 9V instead of 18V. Using DSP technology, NUX is able to offer a mini-pedal with Smart Tap Tempo function. And it's easier to enhance the Chorus mode without volume drop issue in the digital world, and keep the same good vibes as analog sound.

Adjust the Intensity knob first:

In Chorus mode, it will change the depth of the sweeping effect. In Vibrato mode, it will change the degree of pitch modulation.

Adjust the Speed knob last:

At lower settings (counter clockwise), it will produce slow, sweeping effects. At higher settings (clockwise), it will produce rapid, shimmery pulsing.

Mini but mighty! It also supports Stereo input & output. (Use 1/4" TRS plug, and choose Stereo mode.)

*All of the brand and model names mentioned on this page are Trademarks of their respective owners, which are in no way associated or affiliated with NUX Effects and Cherub Technology CO. LTD.

Operation DC jack Red Vise Blue Cherts TAP switch & indicator VOLUME knob VOLUME knob USB-C port OUTPUT FS INDICATOR FOOTSWITCH FOOTSWITCH

Control Panel SPEED knob

Controls rate of modulation.

VOLUME knob

Adjusts total output gain.

INTENSITY knob

Adjusts depth of effect.

TAP switch & indicator

Short press it, you can switch the models. "Red"=Vibe, "Blue"=Chorus. In Chorus mode, it will change the depth of the sweeping effect. In Vibrato mode, it will change the degree of pitch modulation.

Hold the TAP switch to boot-up the pedal can choose "Mono" or "Stereo". While you boot-up the pedal, if the Tap Switch Indicator flashes "Blue" = Mono. "Red" = Stereo.

FOOTSWITCH & FS INDICATOR

Press once to engage/disengage the effect. Press twice, it will become Smart Tap Tempo. In the meantime, the speed is related to tap tempo. (The FS indicator will flash as current BPM.)

While the effect is engaged, the FS indicator will show "Red". While the effect is disengaged, the FS indicator will turn off.

I/O Jacks

DC jack

Use ONLY: 9V Negative Tip power with more than 100mA. (The power consumption is less than 100mA.)

USB-C port

The USB-C port is for firmware update. Connect USB cable to a PC and hold the footswitch to boot-up the device and to enter the DFU (Device Firmware Update) mode. Once connected you can do firmware updates using DFU updater software

You can download the related firmware and firmware update guide from product page.

INPUT

Connect the cable from guitar side.

It also supports Stereo input & output. (Use 1/4" TRS plug, and choose Stereo mode.)

OUTPUT

Connect the OUTPUT signal to amp side.

It also supports Stereo input & output. (Use 1/4" TRS plug, and choose Stereo mode.)



Features

- 2 models in the mini enclosure.
- Chorus mode, Intensity will change the depth of the sweeping effect.
- Vibrato mode, Intensity will change the degree of pitch modulation
- Smart Tap Tempo.
- True Bypass or Buffer Bypass(Trails).
- True Bypass or Bi
 Supports Stereo.
- Low power consumption. (less than 100mA)
- Analog dry signal for low noise and zero latency.

Specifications

Input Impedance: 1MΩ
 Output Impedance: 10kΩ

Dynamic Range: 103dB

DSP Processing: 48kHz / 32bit
 A/D D/A Sampling Rate: 48kHz / 24bit

Power: 9V DC (Negative tip, Optional ACD-006A adapter)

Current Draw: less than 100mA

Dimensions: 94mm(L) x 51mm(W) x 53mm(H)

Weight: 175g

Accessories

- Owner's manual
- Warranty card
- * Specification may change without notice.

THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B. digital device, pursuant to Part 15 of the Complex has been listed as an expected provide resounable protection against harmful interference in a residential interference in a residential interference provide resounable protection against harmful interference in an esidential tender frequency uses, and can anadiate radio frequency energy and, if not installed and used in accordance with the instructions, may be energy and, if not installed and used in accordance with the instructions, may be energy and, if not installed not communications. However, there is no no communications however, there is no no communications the very large transfer installation. If this interference but not not communication recipion, which can be determined by furning the equipment off and on, the user is encouraged to two to correct the interference by one nor nor of the following measures:

- · Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the
 receiver is connected
- . Consult the dealer or an experienced radio/TV technician for help.

©Cherub Technology Co., Ltd.

All Rights Reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Cherufb Technology Co., Ltd.

产品简介

NUX Voodoo Vibe (NCH-3)是一款迷你Uni-Vibe(联合共鸣)效果器。它内置了两种不同的效果:Chorus和Vibe, 您可以使用TAP按键切换所需效果。老派的Uni-Vibe通过模拟真实的旋转喇叭来实现宏大的30音效,这种美妙且令人难以忘怀的声音很难不让人联想到70年代Hendrix在舞台上演出时沉醉的面部表情。

NCH-3的设计灵感来自于Dunlop® Uni-Vibe®华丽的音色。

先动INTENSITY旋钮

Chorus模式下,INTENSITY旋钮控制扫频的深度; Vibe模式下,INTENSITY旋钮控制音高调制程度。

最后动SPEED旋钮

SPEED旋钮处于低位时,NCH-3产生柔和的扫频音色;SPEED旋钮处于高位时,NCH-3产生急促、闪耀的音色。

*本说明书中所提及的产品名称、注册商标和公司名称属于其各所有者,与 纽克斯效果器或深圳市蔚科电子科技开发有限公司无任何关联或附属关系。 提及仅用于功能或特件说明。而非侵犯其各所有者的各项权利。

操作说明



控制面板 SPEED旋钮

调节调制效果速率。

VOLUME旋钮

调节整体输出增益。

INTENSITY旋钮

调节效果的深度。

TAP按键及背光灯

切扱効里模式 短按此按键来切换效果模式。

TAP按键背光灯状态与效果模式对应关系如下: TAP按键亭红色背光 = "Vihe" 模式:

TAP按键亭蓝色背光 = "Chorus" 模式。

切塩輸入/輸出模式

NCH-3胚支持单声道输入/输出又支持立体声输入 /输出, 您可以按住TAP按键再连接电源话配器来

切换输入/输出模式。TAP按键背光灯状态与输入 /输出模式对应关系如下:

TAP按键亭蓝色背光 = 单亩道输 λ/输出模式: TAP按键亭红色背光 = 立体声输入/输出模式。

效果器踩钉及踩钉指示灯

●开户/关闭效果 踩效果器踩钉-次来开启或关闭效果, 效果外干

开启状态时踩钉指示灯为红色: 效果处于关闭状 态时踩钉指示灯处干熄灭状态。

切換直涌模式 NCH-3既支持缓冲直通 (Buffer Bypass) 模式又支 持直直诵模式 (True Bypass), 您可以按住效果

器踩钉再连接电源适配器来切换直通模式。踩钉 指示灯与直诵模式对应关系如下:

绿色 = 缓冲直通模式:

红色 = 直直诵模式。

●智能打占设速 效果外干开启状态时,以需要的速度连续踩效果 器踩钉两次以上来设定效果速度, 完成设速后踩 钉指示灯会以设定好的速度连续闪烁。

1/0 接口

DC 9V电源接口 请使用合格的 输出接口为内负外正的9V电源话配

器为本产品供申、我们建议您洗配NUX ACD-006A申 源话配器, 因为使用不兼容的电源话配器可能会引 起噪音甚至功能故障.

USB-C接口

IISR-C数据交换接口, 请使用合格的USB-C数据线将 本产品连接至您的电脑进行固件更新。产品新周 件。 固件更新指菌请移步至我司官网NCH-3产品页 面
有
カ
カ
下
裁

INPLIT接口

6.35mm信号输入接口、请将吉他连接至本接口。

OUTPUT接口

6.35mm信号输出接口, 请将吉他音箱连接至本接

注意: 如果要使用立体声输入/输出, 请务必将输 入/输出模式设置为立体声并使用立体声导线 (TRS patch cable) 连接。



产品特点

- 集两种效果干一体
- Chorus模式, INTENSITY旋钮控制扫频的深度
- Vibe模式, INTENSITY旋钮控制音高调制程度
- ●智能打点设速 (Smart Tap Tempo)
- ●可切換缓冲器直通 (Buffer Bypass) 或真直通模式 (True Bypass)
- ●支持立体声输入/输出
- ●低功耗 (需求电流小于100mA)
- ●低噪声零延迟模拟干音直通 (Analog Dry Through)

技术规格

輸入阻抗: 1MΩ輸出阻抗: 10kΩ動态范围: 103dB

●数字音频信号处理: 48kHz/32bit

●AD转换/DA转换: 48kHz / 24bit

●电源: 9V直流电源内负外正(选配NUX ACD-006A)

●需求电流:小于100mA

●体积: 94mm (长) x 51mm (宽) x 53mm (高)

●重量: 175q

*技术规格如有变更恕不另行通知。

随机附件

●使用说明书 ●保修卡

有关产品中所含有害物质的说明

为了控制和减少电器电子产品废弃后对环境造成的污染。本资料就 本公司产品中所含的特定有害物质及其安全性予以说明。 木资料活用于2016年7月1号以后木公司所制造的产品

环保使用期限



此标志话用于在中国国内销售的由子信息产品 表示环 保使用期限的年数。所谓环保使用期限是指在制造日起 的规定期限内, 产品中所含的有害物质不致引起环境污 染. 不会对人身, 财产造成严重的不良影响, 环保使用 期限仅在遵照产品使用说明、正确使用产品的条件下才 有效, 不当的使用, 将会导致有害物质泄漏的危险,

产品中有害物质的名称及含量

<u></u>							
部件名称		有害物质					
		铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联笨 (PBB)	多溴二苯醚 (PBDE)
主体	塑胶件	0	0	0	0	0	0
	五金件	×	0	0	0	0	0
	硅胶件	0	0	0	0	0	0
	内置电路板	×	0	0	0	0	0
附件	*交流电源适配器、线缆	×	0	0	0	0	0

- *表示某些产品可能不含有这些项目,上表当中的信息仅在产品 含有这些项目时活用.
- 本表格依据SJ/T 11364的规定编制。
- O:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下.
- x:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572规定的限量要求,因根据现有的技术水平,还没有什 么物质能够代替它.

保护环境

如果需要废弃本产品,请遵循本地相关指引,请勿随意丢弃或作为 生活垃圾处理, 以避免对环境造成污染。

质量承诺

空受的 NULISY 田户·

在你使用NUNK 产品时 请仔细参阅产品说明书 当你有疑问和困难 时, 请拨打售后服务执线: 400-990-9866

- 一周内出现所量问题可退货退款
 一年内出现所量问题可负费维修
- ■一日内出现居景问题可调换 ■终身享有咨询和维修服务 [请向销售商索取下规发票并予以保存]

垫修政策

- 何塩政策·
- 1 消费者通过正规授权渠道购买的产品 自购机之日紀1个日之内 . 在正常使用情况下出现非人为的产品性能故障 日产品外观及包装保 持完好、可向所购机的经销商换机。
- 2. 消费者在操机时应出示由经销商开出的购机凭证,否则经销商 可以不予更换
- 保修政策・
- 消费者通过正规授权渠道购买的产品(以发票所示销售方为准)。 白胸罕之日起1年内,若出现非人为损坏的性能故障。可享有免费维修 服名
- 2. 对于超过1年或人为及不可抗力因素造成损坏的产品。 我司可 提供有偿维修服务

*本售后政策仅适用于中国大陆地区、其它国家及地区以当地售后政策 及法律法规为准。

合格证

Certificate

检验思 迷你联合共鸣效果器 生产日期 쩐 목

本产品经检验合格

执行标准: Q/WKDZ 001-2020 This product is inspected and approved. Product is certificated with Q/WKDZ 001-2020

NCH-3

制造商: 深圳市前科电子科技开发有限公司 制造商地址: 深圳市南山区校口兴华路6号南海倉库1号楼 507 申诉: 0755-2686 9866 同址: www.nusetx.com 生产商: 快海市原料科技开发有限公司 生产 商地址:珠海市高新区唐家湾镇科技九路10号 电话: 0756-3689866