


PH-50 Phaser Pedal

174.222UK



Functions

- 1. RATE Adjusts the speed of the phase shift rotation
- 2. RES Adjusts the resonance/feedback, altering the focus of the phasing effect
- 3. DEPTH Adjusts the amount by which the phase is shifted
- 4. Output 6.3mm mono jack connector
- 5. D.C. In DC jack for optional mains adapter
- 6. Input 6.3mm mono jack connector
- 7. Indicator LED Shows when effect is on (when it appears dim, replace battery)
- 8. Pedal Switch Turns Effect On/Off
- 9. Battery housing Compartment underneath for 9V battery

Notes on use

- Connecting to the Input jack enables the battery, please disconnect when not in use to preserve the battery
- Before connecting to an instrument, ensure amplifier volume is turned down

Specifications

Input Impedance: 1MΩOutput Impedance: 10kΩ

Power Supply: 9Vdc (battery or optional mains adapter) 14mA

© chord 2009 www.chordmusicuk.com