


# **DL-50 Analogue Delay Pedal**

# 174.231UK



#### **Functions**

- 1. D. TIME Adjusts the time interval of each delay
- 2. FEEDBACK Adjusts the amount of delayed signal fed back into the delay line, varying the number of repeats
- 3. D. LEVEL Adjusts the balance between delayed and dry signal
- 4. Output 6.3mm mono jack connector
- 5. D.C. In DC jack for optional mains adapter
- 6. Input 6.3mm mono jack connector
- 7. Indicator LED Shows when effect is on (when it appears dim, replace battery)
- 8. Pedal Switch Turns Effect On/Off
- 9. Battery housing Compartment underneath for 9V battery

# Notes on use

- Connecting to the Input jack enables the battery, please disconnect when not in use to preserve the battery
- Before connecting to an instrument, ensure amplifier volume is turned down

# **Specifications**

Input Impedance: 1MΩ
Output Impedance: >10kΩ

Power Supply: 9Vdc (battery or optional mains adapter) 12mA

© chord 2009 www.chordmusicuk.com