





TU-50 Pedal Tuner

174.243UK



Functions

1. Indicator LED – Shows when tuner is on (when it appears dim, replace battery)
2. LED Digit Indicator - see table below.



C C# D D# E F F# G G# A A# B

3. Flat (*b*) and Sharp (#) indicators. To the left shows note is too flat and to the right shows note is too sharp
4. Input – 6.3mm mono jack connector
5. Output Jacks – OUT 1 is through and OUT 2 is muted when tuning.
6. D.C. In – DC jack for optional mains adapter
7. Pedal Switch – Turns tuner function On/Off

Notes on use

- Connecting to the Input jack enables the battery, please disconnect when not in use to preserve the battery
- Before connecting to an instrument, ensure amplifier volume is turned down

Specifications

- Power Supply: 9Vdc (battery or optional mains adapter)
- Tuning Frequency Range: 31.7722 – 4022.904Hz (C2 – B4)
- Tuning Precision: ± 2 cent