




## PH-50 Phaser Pedal

174.222UK



### Functions

1. RATE – Adjusts the speed of the phase shift rotation
2. RES – Adjusts the resonance/feedback, altering the focus of the phasing effect
3. DEPTH – Adjusts the amount by which the phase is shifted
4. Output – 6.3mm mono jack connector
5. D.C. In – DC jack for optional mains adapter
6. Input – 6.3mm mono jack connector
7. Indicator LED – Shows when effect is on (when it appears dim, replace battery)
8. Pedal Switch – Turns Effect On/Off
9. Battery housing – Compartment underneath for 9V battery

### Notes on use

- Connecting to the Input jack enables the battery, please disconnect when not in use to preserve the battery
- Before connecting to an instrument, ensure amplifier volume is turned down

### Specifications

- Input Impedance: 1M $\Omega$
- Output Impedance: 10k $\Omega$
- Power Supply: 9Vdc (battery or optional mains adapter) 14mA